

## BRASS SWING CHECK VALVE F & F BSP/P



SIZE INCH	SIZE MM	PART No.
1/2	12	SWCH12
3/4	20	SWCH20
1	25	SWCH25
1 1/4	32	SWCH32
1 1/2	38	SWCH38
2	50	SWCH50
2 1/2	63	SWCH63
3	76	SWCH76
4	100	SWCH100